

## **SULFITE TEST KIT:**

Sulfite ( $\text{SO}_3^{2-}$ ) Test Kit for Water (Sensitivity: 1 drop iodur/iodat solution is equal to 0,5 mg/l)

- 1) Rinse the test tube with the water to be tested and fill to the 5 ml mark using injector.
- 2) Add 4 drops of **Sulfite-B Indicator** to the test tube place the stopper and shake very well.
- 3) Add 3 drops of **Sulfite-C Indicator (Color Indicator)** the test tube place the stopper and shake very well.
- 4) Add **Sulfite-A Indicator (Titration Solution)** drop by drop. Color change is controlled by waiting after every drop.
- 5) When you see the blue color titration ends. Multiply total drops by 0,5 obtain sulfite concentration as ppm.