

DESCRIPTION

TEAK CLEANER is an acidic powder used to clean (shine) the wooden surfaces. It can be used on all types of wooden, teak surfaces. After the cleaning it leaves shiny and clean surface.

Chemical Name	: Chemical Mixture
Document No	: SP-KS-077
Trade Name	: TEAK CLEANER (DECK CLEANER)
Usage	: Wooden and teak surfaces.

A.ORGANIC PROPERTIES

Appearance	
Physical State (20°C)	: Crystal powder
Color	: White
Odor	: Odorless

B.PHYSICAL PROPERTIES

pH	: 1.0 - 2.0
Molecular weight	:-
Explosion Limit	: None
Flash point	: None
Relative Density	: 1.05 – 1.15 g/cm3
Solubility	: Limited soluble in water.

APPLICATION, FEATURES & BENEFITS

- ✓ It is fully environmental and harmless for health. Fully biodegradable.
- \checkmark It is suitable for all type of wooden and teak.
- \checkmark It cleans and shines the scale, sludge, dirt, micro organismic particles.
- \checkmark After cleaning, it brings a new view to the surface.

STORAGE INFORMATION

Packed in original plastic boxes each 25 Kg. Storage period is 3 years.



DIRECTIONS FOR USE/APPLICATIONS & DOSAGE RATES

TEAK CLEANER must be diluted with fresh water. Prepare a solution at the concentration of 5-10%. Use a water-jet or a spraying machine to apply TEAK CLEANER to the wooden surfaces. Wait for 10-30 minutes, then brush the surface, after brushing if needed wash the applied surfaces with clean fresh water.